

Installation Instructions Two Hole Cable Clamp

1) Position the cable clamp and 2 bolts (not supplied) onto the support structure.



2F Clamp



2) Install the cable.



3) Locate the other half of the cable clamp. Secure with 2 fastening nuts and washers (not supplied) and tighten.



4) Important. Do not over tighten the cleat. The cleat should secure the cable but does not need to be so tight that the cable bulges at either side of the cleat.





Inst 42 - Two Hole Cable Clamp

Issue 04

24/08/11



Thorne & Derrick
+44 (0) 191 410 4292 INTERNATIONAL www.powerandcables.com